

Installing a Ribbon Polaroid P3500S/P5500S

1) Unwrap the ribbon, and prepare the ribbon holder by removing the old ribbon and old cleaning roller.





2) Place the ribbon on the ribbon holder (see left picture)

3) Place the new cleaning roller on the blue spindle.





4) Place the assembled cleaning roller back on the ribbon holder using the hooks. The assembly should click into place.

5) Peel off the cleaning roller's protective cover.

At this point, you can put the ribbon holder back into the printer and begin printing!

